



Ultra-ADA Pads

Cast-In Place (Wet-Set)

I N S T R U C T I O N S

Pedestrian Safety: Create a barricade to pedestrian traffic so the Ultra-ADA Pads can be safely installed while the concrete is allowed to cure.

Conditions: Pour and finish concrete according to contract drawings. Maintain the slump range between 4-6. Make certain to check the slope using a level.

Materials: Standard Mason's tools are required for the installation. No additional material is needed.

ADA Pad Installation:

1. Place the ADA Pad 6-8 inches from the curb line. Set the pad into the wet concrete and apply pressure using a wiggling motion. Make certain not to push the pad too far into the concrete. The concrete should be level with the top surface of the Pad.
2. Use a trowel to finish the concrete and recheck the slope using a level.
3. The final step is to use a sponge to remove any excess concrete that may have been left on the surface of the ADA Pads. Note: dried concrete is easy to remove from the surface of the ADA Pads (with a brush) without any damage.
4. During the ADA Pad installation and the initial concrete curing stage, it is imperative that no traffic is allowed on the pads.