

Ultra-Power Sprayer[®] Part# 4130, 4131, and 4132 Quick Start Guide for Ultra-Ever Dry

- 1. Use appropriate PPE (gloves, respirator, goggles, paint suit, etc.)
- 2. Prepare and clean surfaces prior to coating for better adhesion
- 3. Shake or mechanically mix the Bottom Coat for 5-10 minutes prior to application
- 4. Adjust the Ultra-Power Sprayer pattern to apply thin, even coats do not pool the coating
- 5. Allow the Bottom Coat to dry for at least 30 minutes before applying the Top Coat (do not apply Top Coat if the Bottom Coat is still wet)
- 6. Clean the Ultra-Power Sprayer by spraying a small amount of xylene into a rag or waste container and allow the sprayer to dry before applying the Top Coat
- 7. Shake or mechanically mix the Top Coat for 3-5 minutes prior to application
- 8. Allow the Top Coat to dry for at least 30 minutes prior to challenging with liquid allowing the Top Coat to dry longer (even overnight) can improve results
- 9. Clean the Ultra-Power Sprayer by spraying a small amount of xylene into a rag or waste container
- 10. Take apart and thoroughly clean all components of the Ultra-Power Sprayer gun with xylene and allow to air dry before storing
- 11. Dispose of xylene and cleaning materials according to local regulations
- 12. Clean the air filter on the back of the Ultra-Power Sprayer turbine after each use with water or compressed air
- 13. Refer to the specific instructions for Ultra-Ever Dry and the Ultra-Power Sprayer for more detailed information



UltraTech International, Inc. 1-904-292-1611 1-800-353-1611 www.UltraEverDry.com

11542 Davis Creek Court, Jacksonville, Florida 32256 USA

