


## Instruction Sheet

**Ultra-Modular IBC SpillPallets** 

1-800-353-1611

www.SpillContainment.com

Assembly Instructions for Expansion Tank



**NOTES:** MAKE SURE ALL PLUG

WRENCH AND HOLE SAW KIT MUST BE ASSEMBLIES ARE TIGHT BEFORE PURCHASE SEPARATELY; PORTABLE PUTTING THIS PRODUCT IN USE. DRILL AND (2) 3/8" DRIVE RACHETS NOT PROVIDED.

in the center of the drill point and cut a hole through the sidewall. Repeat Step 3 for the remaining drill points in the sidewalls. (Requires two holes each sidewall) Repeat Steps 2, 3 and 4 for all mating sidewalls. CAUTION: only cut holes into the sidewalls that are intended to have a (3)bulk head fitting. Remove the grates from the (1)pallet or open the lid of the (2)expansion tank to access the backside of hole. From the inside, insert a 1 1/4" (3A)bulk head fitting through the hole. Place two (3B)gaskets onto the inserted (3A)bulk head fitting before passing the (3A)bulk head fitting through the hole in the mating sidewall. Note: The (3B)gaskets should be between the mating sidewalls. Start a (3C)hex nut onto the (3A)bulk head fitting. Do not tighten. Note: These are left handed

Locate the two drill points on each mating sidewall of the (1)pallet and/or (2)expansion tank. Note: the drill points are dimples in the sidewall that are located approximately 2 <sup>1</sup>/<sub>2</sub>"

threads. Side of the (3C)hex nut with the word "tighten" and a directional arrow should be facing away from the (3A)bulk head fitting when attaching the (3C)hex nut to the (3A)bulk head fitting.

Repeat Steps 6 and 7 for the remaining mating holes in the sidewalls.

Place the (1)pallets and /or (2)expansion tanks in the desired configuration.

from the bottom of the (1)pallet or (2)expansion tank and are 18" apart.

Using the (4B)2 3/8" hole saw, carefully place the drill bit of the hole saw

Tighten the (3A)bulk head fittings using two 3/8" drive ratchets (not provided) along with the (4C)hex socket wrench and the (4A)lug spanner wrench. Note: (4A)lug spanner wrench is designed to fit over the lugs on the round side of the (3A)bulk head fitting. Tighten the (3A)bulk head fitting until the mating sidewalls are pulled together and the (3B)gaskets are slightly compressed.

Repeat steps 6 through 9 for the remaining sidewalls that were cut with the (4B)hole saw.

			P/N 1125	P/N 1126	P/N 1127	P/N 1128	
ÍTEM	PART	DESCRIPTION					
1	9630	YELLOW PALLET	2	3	4	5	
2	1124	YELLOW 66 GAL. EXPANSION TANK	2	2	1	0	
3	1117	1.25" BULK HEAD FITTING ASSEMBLY	3	4	4	4	
3A		BULK HEAD FITTING (2 per pack)					
3B		GASKET (4 per pack)					
3C		HEX NUT (2 per pack)					
4	1118	WRENCH AND HOLE SAW KIT	1	1	1	1	
4A		3/8" DRIVE LUG SPANNER WRENCH					
4B		2 3/8" HOLE SAW WITH ARBOR					
4C		3/8" DRIVE SOCKET WRENCH					

12-26-07 r. 3