



ULTRATECH
INTERNATIONAL, INC.

Ultra-Gutter Guard Plus®

INSTALLATION INSTRUCTIONS



STEP 1: Remove GutterGuard Plus grids and sleeves from box (6-foot unit shown).



STEP 2: Snap off stabilizer arms (2-pieces per arm). Set aside for step 5.



STEP 3: Slide grids together.



STEP 4: Slide assembled grids into outer sleeve.



STEP 5: Install stabilizer arms (correct side is noted on grids)

STEP 6: Seal hook & loop fastener strips.



STEP 7: Insert 7 lb. minimum weight into sleeve in back of unit. (Optional weight available - p/n 9148)

STEP 8: Slide sleeve into curb throat, holding unit tight to curb face. (Leave 12" overlap on each end of curb opening)

STEP 9: Tie-back straps can be used for additional anchoring if desired.

STEP 10: Clean unit after each wet weather event.



OTHER PRODUCTS AVAILABLE FROM ULTRATECH
 VISIT www.spillcontainment.com FOR MORE INFORMATION



ULTRATECH
 INTERNATIONAL, INC.

UltraTech International, Inc. · 11542 Davis Creek Court, Jacksonville, Florida 32256 USA
 (800) 353-1611 · 1-904-292-1611 · spillcontainment.com