



ULTRATECH
INTERNATIONAL, INC

Ultra-HydroKleen® Installation Instructions

1. Remove grate from top of catch basin.
2. Clean grate lip of debris.
3. Drop unit into opening with stainless frame resting flush on the catch basin lip.
4. Pull the Diverter Pad (rubber pad covering the media side of the unit).
5. Remove plastic covering from one Sorb-44 media bag if using an 18" high or smaller unit and one AC media bag. Use two Sorb-44 media bags if using a unit taller than 18".*
6. Place AC Filter (activated carbon) flat on bottom of filter chamber (chamber with holes in bottom. The perimeter seamed side should be up. **
7. Lay one or two Sorb-44 media bags (depending on height of unit, see 5. above) flat on top of carbon bag. The perimeter seamed side should be up. **
8. Place the Diverter Pad back into place to force all liquid entering the unit to flow into the sediment chamber half of the unit.
9. Replace the Grate.

* There are two sorb-44 media bags in each set of media. With 18" units only one sorb-44 bag is used initially. This top sorb-44 bag should be replaced half way through the media cycle with the second sorb-44 bag. Do not change the activated carbon bag at this time. All media including the activated carbon bag should be changed every 3 to 6 months depending on site conditions.

** You will notice the shape of the media bags fit the shape of the filter chamber.

