



Ultra-Containment Berm® Repair Tape

Instructions

1. Make sure that the surface where you will be installing the tape is clean, dry and dust-free. Thoroughly dust the area, clean it with an alcohol solution (if applicable) and let it completely dry before applying the tape.
2. Peel the tape from the roll. NOTE: Avoid excessive contact with the self-fusing sides as oils from your hands or any other foreign materials can contaminate the adhesive and lessen its bonding strength.
3. Conform the tape with the surface's texture to eliminate any gaps that may exist in between the tape and the surface. The repair tape is conformable so make sure that you mold and press it against the surface's bumps, curves, and empty areas, covering every possible hole.
4. Eliminate any air bubbles which may exist by applying pressure on the area of application.
5. Allow the tape to cure, dry and acclimatize overnight before use. If this isn't possible, then letting the tape set for at least 3-4 hours should be sufficient.

