



ULTRATECH
INTERNATIONAL, INC

Ultra-HydroKleen®

Maintenance and Care Instructions

1. Inspect the Ultra-HydroKleen every three months or after significant rainfall events.
 - If the sediment chamber is full (the level of sediment and debris is within 1" of the flow holes located in the center plate), remove the catch basin grate and extract the sediment and debris located in the sediment chamber.
 - Dispose of the extracted contents according to state and local regulations.
 - In many cases the extracted sediment and debris may be sent for landfill disposal.
2. At a minimum, the Ultra-HydroKleen needs to have the filters removed, disposed of and replaced every six months.
 - Dispose of the filters according to state and local regulations.
 - If the HydroKleen is a Sampling Model, the end user should monitor the effluent from the HydroKleen and change out the filters based on the data obtained from the samples using their own guidelines or local and state requirements.
 - By using sampling data for filter change-out decisions the six month minimum may not apply.
 - If very little pollution is entering the HydroKleen, then the filters may not need to be changed out until one year or more.

