

## Ultra-Grate Guard<sup>®</sup>

## **INSTALLATION**

- 1. The empty Ultra-GrateGuard<sup>™</sup> unit should be placed over the grate as the grate stands on end.
- 2. Tuck the enclosure flap inside to completely enclose the grate.
- 3. Holding the lifting handles, being careful not to damage the sewn fabric unit, insert the grate into its frame street side edge first then lower back into place.
- 4. If the unit is not installed in this manner, it will not function properly. The user is solely responsible for compliance with installation laws and regulations. The manufacturer or seller assumes no responsibility for proper or improper installation.

## MAINTENANCE AND DISPOSAL

- 1. Remove all accumulated sediment and debris from surface and vicinity of unit after each storm event. If the unit is not maintained in this manner, it will not function properly.
- 2. Dispose of unit and/or absorbent in accordance with applicable Federal, state and local environmental laws and regulations. The user is solely responsible for compliance with maintenance and disposal laws and regulations. The manufacturer or seller assumes no responsibility for proper or improper maintenance or disposal.



Rev. 04.16.25