

Ultra-Pellet Pond®

Instructions

- 1. After unboxing the Ultra-Pellet Pond_® and four included piece of rebar, unfold and inspect the material for any rips, tears or damage. Please contact UltraTech customer service at 904.292.1611 if any issues are found.
- 2. Flip the pond over so the bottom is facing up.
- 3. Insert one piece of rebar into each sleeve heat-sealed into the bottom of the pond.
- 4. Insure that the flap at the end of each sleeve is pulled out so the rebar is "locked" into place and won't slide out when the Ultra-Pellet Pond is being moved around.
- 5. Flip the pond back right side up.
- 6. Your Ultra-Pellet Pond_® is now ready for use.



NOTE: Pellets should be removed periodically, especially from around/on the drain to reduce the chance of flooding.