



**ULTRATECH**  
INTERNATIONAL, INC

## Ultra-Drain Plug

### Instructions

*Follow these easy steps to assure maximum effectiveness:*

1. Use the Ultra-Drain Plug™ to prevent liquids from entering a 2", 3", 4", 6", 8", 10" or 12" diameter drain. Each Ultra-Drain Plug™ contains a removable eye bolt. The eye bolt assists in placement and removal of plugs. **Note:** Eye bolt should be removed after placement of drain plug to prevent tripping hazard.
2. Insert the Ultra-Drain Plug™ into the drain to the point where snug fit is achieved. Make sure the entire diameter of the drain is completely sealed.
3. Always wash the Ultra-Drain Plug™ before reuse or storage. Wash the Ultra-Drain Plug™ using warm water with a non-abrasive detergent or petroleum solvent cleaner. Dry the Ultra-Drain Plug™ before storage. Store out of direct sunlight, and at room temperature.

#### **IMPORTANT NOTES:**

1. If the Ultra-Drain Plug™ comes in contact with hazardous chemicals, always follow your state and local regulations regarding proper decontamination and waste handling procedures.
2. The Ultra-Drain Plug™ will become less flexible if stored in cold temperatures.
3. Due to the nature of softer urethane, the physical properties of these products may change with exposure to certain environmental conditions like temperature, humidity and UV radiation. Please inspect the stored product regularly to ensure it is in a usable state.
4. For chemical compatibility information, please visit the support section of our website [www.spillcontainment.com](http://www.spillcontainment.com).

